

Extra torque for working on Ford engines: TOOL BOX V10

This tool box contains a torque multiplier complete with accessories. This is absolutely essential for tightening the crankshaft belt pulley or assembling the cylinder head, for example, on some models of the Ford EcoBoost and EcoBlue engines as well as other engines. TOOL BOX V10 is therefore the perfect add-on for TOOL BOX V09, which is used specifically when working on belt-in-oil engines.

Contents

- > Torque multiplier
- > Retaining plate
- > Supporting arm
- > Fastening bolts
- > Reinforced sockets
- > Spacer plate

Benefits

- > High-quality tools for professional use
- > Made of robust, high-grade steel
- > Exclusive set of tools only available from Continental
- > Clearly organized storage in a sturdy case
- > Tools available to order individually in the event of damage or loss
- > Five-year guarantee:
www.continental-ep.com/5



Parts list/area of application TOOL BOX V10

Item	Description	Ford	Displacement	OE tool no.	
		Engine codes	K model		
1	Torque multiplier	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	118618; 55105; 108797; 142732; 55106; 59492; 108800; 108790; 56757; 56760; 108791; 118620; 131656; 38703; 106349; 58967; 58968; 108811; 136547; 108813; 136546; 108808; 131963; 129172; 129171; 121236; 29567; 31094; 121237; 29566; 31095; 129170; 30438; 113328; 113330; 30487; 108777; 56758; 108778; 56761; 124773; 111088; 111103; 101091; 101058; 101057	1.0	303-1611
2	Torque multiplier connector	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	118618; 55105; 108797; 142732; 55106; 59492; 108800; 108790; 56757; 56760; 108791; 118620; 131656; 38703; 106349; 58967; 58968; 108811; 136547; 108813; 136546; 108808; 131963; 129172; 129171; 121236; 29567; 31094; 121237; 29566; 31095; 129170; 30438; 113328; 113330; 30487; 108777; 56758; 108778; 56761; 124773; 111088; 111103; 101091; 101058; 101057	1.0	303-1611-01
3	Torque multiplier mounting plate	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	118618; 55105; 108797; 142732; 55106; 59492; 108800; 108790; 56757; 56760; 108791; 118620; 131656; 38703; 106349; 58967; 58968; 108811; 136547; 108813; 136546; 108808; 131963; 129172; 129171; 121236; 29567; 31094; 121237; 29566; 31095; 129170; 30438; 113328; 113330; 30487; 108777; 56758; 108778; 56761; 124773; 111088; 111103; 101091; 101058; 101057	1.0	303-1611-02

